

# NEEDLE CONFIGURATIONS

- **1-liner**

Fine hairlines, eyeliner, lash enhancement, on large-pored and wrinkled skin for lip contours

**Please note: low skin resistance, be sure not to puncture too deeply!**

0,4mm **B**
- **1-micro thinnest needle point**

Fine, single hairstrokes

**Please note: low skin resistance, be sure not to puncture too deeply!**

0,4mm **B**
- **3-liner**

Eyeliner, lip contour, wider lines, camouflage, shading

0,3mm **B**
- **3-micro thinnest needle points**

Eyeliner, lash enhancement, lip contour

0,18mm **B**
- **3-outline**

Lash enhancement, lip contour, soft lines

0,25mm **B**
- **3-power**

Eyeliner, lip contour

**Please note: Use sparingly and apply the color using only a few passes. Ideal for color refreshment. Strong color application, very dense line.**

0,3mm
- |||

**3-slope**

areola, scars, camouflage

0,4mm **!**
- **4-flat**

Lip shading, areola, scar camouflage

0,35mm **B**
- **5-power**

Eyeliner, lip contour, wide, soft color application

**Please note: Use sparingly and apply the color using only a few passes. Ideal for color refreshment. Strong color application, very dense line.**

0,3mm
- **5-round**

Eyeliner, lip contour, wide, soft color application, shading, areola, scars

0,3mm
- **5-shader**

shading, lips, scars, camouflage

0,3mm
- **5-magnum**

Lip shading, areola, scars, camouflage

0,3mm
- |||||

**5-slope**

areola, scars, camouflage

0,4mm **!**
- |||||

**5-v-slope**

areola, scars, camouflage

0,4mm **!**
- **7-round**

Lip shading, areola, scars, camouflage

0,3mm
- **7-power**

Lip shading, areola, scars, camouflage

**Please note: Use sparingly and apply the color using only a few passes. Ideal for color refreshment. Strong color application, very dense line.**

0,3mm
- **9-magnum**

Lip shading, areola, scars, soft color application

0,3mm
- |||||

**10-ditto**

areola, scars, camouflage

0,4mm **!**

**B** For Beginners

**!** Requires special training! Developed by Dr. Linda Dixon. Allows for a wide range of versatile, techniques. If used correctly, all needles penetrate the skin evenly. Work with a 45° angle.